

A close-up photograph of a light-colored wooden table. The top edge is rounded and smooth, showing the natural wood grain. Below the edge, the underside of the table is visible, showing a decorative bracket or support structure. A thick, tapered wooden leg is visible on the right side, also showing the wood grain. The background is a plain, light grey.

WintonsTeak<sup>®</sup>

# A LASTING TOUCH

CARING AND CLEANING  
GUIDE FOR **INDOOR**  
FURNITURE

---

+ **TIMBER**

# TIMBER

## Expected Features of Timber

- As a natural product, timber undergoes gradual natural variations such as the formation of knots, grain and colour changes which add beauty and texture to the furniture.
- It's normal for timber to move i.e expand or contract with weather changes. Dry weather causes the timber to shrink a bit, and our special pen joinery construction allows it to go back to normal once the humidity level rises. Any authentic piece of wood will behave the same, and these innate rotations do not at all affect its quality and sturdiness.
- Also, the dark timbers will lighten, and light timbers will darken with time. Simply say, timber becomes unique and antique as it ages.

## Caring for Timber:

- Dust your furniture regularly with a soft cloth such as flannel or microfibre cloth.
- Use tablecloths, table runners and coasters to help protect surfaces from scratching
- Furniture can be wiped with a damp cloth when necessary
- Clean up spills promptly without any delays. Soak up the affected area with any blotting paper.
- Never ever scrub or scour the timber surface while cleaning as it can get scratched and will also affect the product finishing.
- Keep rotating your accessories that usually sit on the furniture as covered surfaces age differently than the uncovered surfaces.

## ➔ Avoid!

- Do not put your indoor furniture in direct sunlight, as this can cause colour change and hairline cracks in the timber.
- Avoid placing extremely hot and cold objects on the furniture such as a hot saucepan, or a cube of ice as they can leave marks which are hard to remove. Better use coasters.
- Do not allow nail polish remover, hair spray, and corrosive solvents sit on your timber furniture. It can affect the polyurethane finishing of the furniture.
- It is important to use the furniture as it is intended. This means that it is important to not sit on the armrest or tabletop or pivot on the chairs.
- Do not use abrasive material such as sandpaper to remove any stain and this will scratch and remove the polyurethane coatings on the furniture. affect the product finishing.





**If you have any enquiry  
please contact customer  
service team:**

**[customer\\_service@wintonsteak.com](mailto:customer_service@wintonsteak.com)**

**Terms and conditions (of the guide)**

Wintons Teak endeavour to have all information in this guide correct, however, there can be errors, in such case we apologise for any inconvenience caused and it may be necessary to change information in this guide.

